

IF YOU ARE ABOUT TO (i) TETHER AN AUSTRAL MOTORHOME POD TO YOUR VEHICLE OR (ii) UN-TETHER THE POD AND LOWER IT TO THE GROUND, YOU MUST READ THIS FIRST FOR SAFETY REASONS



6 x TIE -DOWN POINTS IN TOTAL



1 x TIE-DOWN IN EACH CORNER



3 x TIE -DOWNS ON EACH SIDE



CORNERS ARE 2 TONNE RATED



LEGS LOWERED ONTO FIRM GROUND



SOLID NON-SLIP PADS UNDER LEGS



LEGS LOWERED ONTO LEVEL GROUND



ALL LEGS MAKE CONTACT SAME TIME



For more information visit

WWW.AUSTRALMOTORHOMES.COM.AU